

SaniForce[®] Ram Packages

3A0591ZAG

EN

For use in sanitary applications to transfer medium to high viscosity fluids. For professional use only.


Not approved for use in European explosive atmosphere locations.

*See **Technical Specifications** on page 27 for model information, including maximum fluid working pressure.*



Important Safety Instructions

Read all warnings and instructions in this manual. Save these instructions.



ti15713a



Contents

Warnings	3	Troubleshooting	18
Configuration Matrix	6	Repair	19
Installation	8	Disconnect Piston Pump	19
Grounding	8	Service Ram Pistons	20
Location	8	Parts	22
Setup	9	Piston Pump Ram Packages	22
Operation	13	Air Controls Kits	27
Pressure Relief Procedure	13	Dimensions	29
Flush Before First Use	13	Technical Specifications	30
Setting Inflatable Seal Pressure	13	Model Weights	31
Starting and Adjusting the Ram	14		
Starting and Adjusting the Pump	15		
Changing Drums	16		
Shutdown	16		
Cleaning Procedure	17		

Related Manuals

Manual in English	Description
3A5798	SaniForce 5:1 Pump, Instructions/Parts
3A5564	SaniForce 6:1 Pump, Parts
3A5799	SaniForce 12:1 Pump, Instructions/Parts
3A5800	SaniForce Air Control, Instructions/Parts

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

 <h2 style="margin: 0;">WARNING</h2>	
    	<p>SKIN INJECTION HAZARD</p> <p>High-pressure fluid from dispensing device, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment.</p> <ul style="list-style-type: none"> • Do not point dispensing device at anyone or at any part of the body. • Do not put your hand over the fluid outlet. • Do not stop or deflect leaks with your hand, body, glove, or rag. • Follow the Pressure Relief Procedure when you stop dispensing and before cleaning, checking, or servicing equipment. • Tighten all fluid connections before operating the equipment. • Check hoses and couplings daily. Replace worn or damaged parts immediately.
 	<p>MOVING PARTS HAZARD</p> <p>Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure and disconnect all power sources.

WARNING



FIRE AND EXPLOSION HAZARD

Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. To help prevent fire and explosion:

- Use equipment only in well ventilated area.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).
- Keep work area free of debris, including solvent, rags and gasoline.
- Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
- Ground all equipment in the work area. See **Grounding** instructions.
- Use only grounded hoses.
- Hold gun firmly to side of grounded pail when triggering into pail.
- If there is static sparking or you feel a shock, **stop operation immediately**. Do not use equipment until you identify and correct the problem.
- Keep a working fire extinguisher in the work area.



EQUIPMENT MISUSE HAZARD

Misuse can cause death or serious injury.

- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Data** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See **Technical Data** in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS from distributor or retailer.
- Do not leave the work area while equipment is energized or under pressure. Turn off all equipment and follow the **Pressure Relief Procedure** when equipment is not in use.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.
- Do not alter or modify equipment.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.



SPLATTER HAZARD

Hot or toxic fluid can cause serious injury if splashed in the eyes or on skin. During blow off of platen, splatter may occur.

- Use minimum air pressure when removing platen from drum.



TOXIC FLUID OR FUMES HAZARD

Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.

- Read MSDSs to know the specific hazards of the fluids you are using.
- Route exhaust away from work area. If diaphragm ruptures, fluid may be exhausted into the air.
- Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.

WARNING



BURN HAZARD

Equipment surfaces and fluid that's heated can become very hot during operation. To avoid severe burns:

- Do not touch hot fluid or equipment.



PERSONAL PROTECTIVE EQUIPMENT

You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.

Configuration Matrix

Check the identification plate (ID) for the Configuration Number of your pump. Use the following matrix to define the components of your system.

Sample Configuration Number: **SDU B01AAA6AA0C21**

SDU	B	01	A	A	A	6	AA	0	C21
Sanitary Drum Unloader	Frame	Pump	Platen	Seal Style	Seal Material	Controls	Accessories	Wash Bin	Certification

Some combinations are not possible. Please check with your local supplier.

Sanitary Drum Unloader	Frame		Pump		Platen		Seal Style	
SDU	B	Carbon Steel	01	5:1 Double Ball	A	20" Conical, inflatable	A	Inflatable
			02	5:1 Priming Piston	B	21.25" Conical, static	B	Static
			03	6:1 Double Ball				
			04	6:1 Priming Piston				
			05	12:1 Priming Piston				


Seal Material		Controls		Accessories		Wash Bin		Certification	
A	Polychloroprene	6	Exposed pneumatic, carbon steel, inflatable	AA	None	0	None	C21	EN 10204 type 2.1
B	EPDM	7	Exposed pneumatic, carbon steel, static						

Approvals

All models are rated:




ATEX models with piston pumps are rated:



Installation

Grounding



Pump: Connect a ground wire (Graco PN 238909) to the ground screw on the bottom cover of the air motor, under the shield. Connect the other end of the ground wire to a true earth ground.

Air and fluid hoses: use only electrically conductive hoses with a maximum of 500 ft. (150 m) combined hose length to ensure grounding continuity. Check electrical resistance of hoses. If total resistance to ground exceeds 25 megohms, replace hose immediately.

Air compressors: follow manufacturer's recommendations.

Dispense valve: ground through connection to a properly grounded fluid hose and pump.

Material supply container: follow local code.

Container(s) that receive material: follow local code.

Solvent pails used when flushing: follow local code. Use only conductive metal pails, placed on a grounded surface. Do not place the pail on a nonconductive surface, such as paper or cardboard, which interrupts grounding continuity.

To maintain grounding continuity when flushing or relieving pressure: hold metal part of the dispense valve firmly to the side of a grounded metal pail, then trigger the valve.

Location

Position the ram so the air controls are easily accessible. Ensure that there is sufficient overhead clearance when the ram is fully raised. See **Repair**, page 18.

Position the ram in an area with adequate access for servicing and cleaning the equipment and adjacent areas to maintain the required level of hygiene. Locate equipment away from sources of air currents, dust, or liquids derived from leakage, condensation, or aerosols.

Using the holes in the ram base as a guide, drill holes for 1/2 in. (13 mm) anchors.

Check that the ram base is level in all directions. If necessary, level the base using metal shims. Secure the base to the floor using 1/2 in. (13 mm) anchors that are long enough to prevent the ram from tipping.

Setup

Reference numbers and letters in parentheses in the text refer to the callouts in the figures and the parts drawings.

Accessories are available from Graco. Make certain all accessories are sized and pressure-rated to meet your system requirements


FIG. 1 is a guide for selecting and installing system components and accessories. Contact your Graco distributor for assistance in designing a system to suit your particular needs.

- **Inflatable Seal (C):** Adjust inflation level so the seal fits snug against the drum. A properly inflated seal wipes the sides of the drum and prevents material from passing the plate, to minimize waste.
- **Main air bleed valve (D):** Required in your system to shut off the air supply to the pump and ram. When closed, the valve bleeds off all air in the ram and pump.

Air and Fluid Accessories

The following accessories are recommended for your system, and are available from your Graco distributor. Make certain all accessories are sized and pressure-rated to meet your system requirements

- **Fluid Drain Valve (M):** Required in your system to relieve fluid pressure between the pump and the dispense device.
- **Fluid Outlet Elbow (P):** Recommended for ram packages with piston pumps. Connects the fluid outlet hose to the pump fluid outlet.
- **Air Line Filter (K):** Removes harmful dirt and moisture from the compressed air supply.
- **Second bleed-type air valve (L):** isolates air line accessories and supply system for servicing. Locate upstream from all other air line accessories.



T116245

Key:

Ram Package Components (Supplied)

- A Pump
- B Ram
- C Inflatable Seal
- D Main Air Bleed Valve (required for pump and ram)
- E Air Assist Air Supply
- F Inflatable Seal Air Supply (partially visible)
- G Ram Director Control
- H Air Controls (*see FIG. 2*)

Accessories (Not Supplied)

- J Air Supply Hose (use 1/2 in. air hose, minimum)
- K Air Line Filter
- L Second Bleed-Type Air Valve
- M Fluid Outlet Hose
- N Fluid Drain Valve (required for pump)
- P Fluid Outlet Elbow

FIG. 1: Typical Installation, Piston Pump




FIG. 2: Exposed Air Control Module

Integrated Air Controls

See FIG. 2. Air inlet size is 3/4 npt(f) on the Exposed Air Controls. The integrated air controls include:

- **Main air valve (BA):** turns air on and off to the system. When closed, the valve relieves pressure downstream.
- **Ram air regulator (BB):** controls ram up and down pressure.
- **Ram director switch/valve (BC):** controls ram direction.
- **Exhaust port with muffler (BD)**
- **Air motor regulator (BE):** Controls air pressure to motor.
- **Air motor switch/slider valve (BF):** turns air on and off to the air motor. When closed, the valve relieves air trapped between it and the air motor.
- **Air assist valve (BG):** turns air on and off to push the ram plate out of an empty drum. Uses line air.
- **Inflatable seal air regulator (BH):** controls air pressure to the inflatable seal.
- **Inflatable seal switch (BJ):** controls the inflation and deflation of the ram plate seal.
- **Air relief valve (BK):** automatically relieves excessive pressure.
- **Seal bleed off valve (BL):** bleeds air from inflatable seal as needed for drum tapering. For Exposed Air Control Modules, See FIG. 2.

Operation

Pressure Relief Procedure

 <h1 style="margin: 0;">WARNING</h1>	
    	<p>Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury from injection, splashing or moving parts. Relieve pressure when you stop pumping and before cleaning, checking, or servicing equipment.</p>

Do not close the main air valve until Step 6. The Enclosed Air Controls will not operate when the main air supply is in the Off position.

1. Close the air motor slider valve (BF). See FIG. 2.
2. Back the ram director air regulator down to zero. Set the ram director switch/valve (BC) to DOWN. The ram will slowly drop.
3. Jog the director valve up and down to bleed air from ram cylinders.
4. Turn the inflatable seal switch (BJ) to off.
5. Open the fluid ball valve and/or dispensing valve to relieve fluid pressure.

6. Close the main air valve (BA).

Flush Before First Use

The sanitary pump was assembled using sanitary lubricant on moving parts and was tested in water. Flush the pump thoroughly with an appropriate cleaning solution or disassemble and sanitize the parts before using the pump. See your separate pump manual for complete flushing and cleaning procedures for a sanitary pump. Check national, state, and local codes for specific limitations.

Setting Inflatable Seal Pressure

1. Set an empty drum on the ram base. Set the director valve (BC) to DOWN. Lower the seal into the drum to the point of the drum's largest inside diameter.
2. Set the inflatable seal switch (BJ) to On. Adjust the seal air regulator until the seal just touches the inside of the drum.
3. Leave regulator set at this setting for this style of drum.
4. Set the inflatable seal switch to Off to deflate seal before raising the ram. Set the director valve (BC) to UP and let the ram rise to its full height.
5. Remove the empty drum.

NOTE: Use the lowest seal pressure possible to achieve desired results. Excessive seal pressure may cause the seal to roll off of the follower plate. To prevent overpressurization, a relief valve limits seal pressure to 30 psi (2.1 bar, 0.21 MPa).

Starting and Adjusting the Ram

WARNING

- Do not inflate the seal when not installed on the follower plate. Wear safety glasses when operating the seal. Seal burst could result in injury.
- Keep hands and fingers away from the ram plate, pump fluid inlet, and lip of the fluid container when raising or lowering the ram to reduce risk of serious injury from moving parts.

1. Close all air regulators and air valves.
2. Turn on the main air supply.
3. Open the main air valve (BA), and set the ram director air regulator (BB) to 2.8 bar, 0.26 MPa (40 psi). Set the director valve (BC) to UP and let the ram rise to its full height.
4. Lubricate inflatable seal (C) with sanitary lubricant.
5. Set a full drum of fluid on the ram base, slide it back against the tube stop, and center it under the follower plate.

6. Remove the drum cover, and smooth the surface of the fluid with a straightedge.
7. Secure the bag liner to the drum with tape or a strap, to prevent it from sliding into the drum.

NOTICE

Do not use drums that have side bungs or large dents with this ram. Rough bung openings or large dents will damage the inflatable seal or stop the ram plate, resulting in a runaway pump.

8. Set the director valve to DOWN. Set ram air regulator at about 40 psi (0.28 MPa, 2.8 bar). Lower the ram until the ram plate is about to enter the drum, and set the valve to neutral. Reposition the drum as necessary so the inflatable seal does not hit the drum lip.

Exposed Controls: To increase or decrease the speed of downward travel on the ram plate, adjust the director valve (BC).

9. Set the director valve to DOWN, and continue to lower the ram until the ram plate contacts the fluid.
10. Set seal air pressure regulator to pressure determined in **Setting Inflatable Seal Pressure**, page 12. Set the inflatable seal switch to On to inflate seal.

NOTE: If fluid leaks past the seal, increase the air pressure to the seal gradually until leaking stops. To prevent overpressurization, a relief valve limits seal pressure to 30 psi (2.1 bar, 0.21 MPa).

Starting and Adjusting the Pump



See FIG. 3, page 14.

1. Be sure the pump air regulator (BE) is closed. Set the ram air regulator (BB) to about 50 psi (0.35 MPa, 3.5 bar). Set the director valve (BC) to DOWN.
2. Start the pump as explained in the separate pump instruction manual.
3. Keep the director valve (BC) set to DOWN while the pump is operating.

Adjusting the Pressure

Different combinations of seal and ram pressure may be necessary for proper seal and pump operation.

- If the pump does not prime properly with heavier fluids, increase air pressure to the ram.
- If fluid is forced out around the inflatable seal, decrease pressure to the ram.
- For diaphragm pump models, adjust DOWN pressure to the minimum level, to ensure that the pump inlet balls seat properly.

If seal pressure builds when the seal enters a tapered portion of the drum, the relieve valve will activate. Turn the seal bleed-off valve (BL) counterclockwise to open it.




FIG. 3. Air Control Module

Changing Drums



Moving parts can pinch, cut, or amputate fingers and other body parts. Keep your hands and fingers away from the priming piston, ram plate, and lip of drum during operation and whenever the pump or ram is charged with air.

1. Stop the pump. Close the air motor valve (BF).
2. Set the inflatable seal valve (BJ) to deflate.
3. Set the director valve (BC) to UP to raise the ram plate.
4. Raise the ram plate until it is completely out of drum.
5. If needed, use air assist (BG) to help lift the ram plate.



Excessive air pressure in the material drum could cause the drum to rupture, causing serious injury and equipment damage. The platen must be free to move out of the drum.

- Never use drum blowoff air assist with a damaged drum.
- Always deflate the seal prior to lifting ram plate or engaging air assist.

6. Remove the empty drum.
7. Inspect the ram plate and, if necessary, remove any remaining material or buildup.
8. Place a full drum on ram base.
9. Lower the ram, and adjust the position of the drum relative to the ram plate, as explained under **Setting Inflatable Seal Pressure** on page 12.

Shutdown

1. Set the director valve (BC) to neutral.
2. Follow **Pressure Relief Procedure**, page 12.
3. Follow the pump shutdown instructions in your separate pump manual.

Cleaning Procedure



NOTE: The following instructions are a basic procedure for cleaning a sanitary ram.

- **Be sure** to follow your national and state sanitary standard codes and local regulations.
 - Use appropriate cleaning and disinfecting agents, at intervals appropriate for product processed.
 - Follow cleaning product manufacturer's instructions.
1. Remove the pump from the fluid container. Operate it to pump out as much fluid as possible.
 2. Flush the system thoroughly with an appropriate cleaning solution.
 3. Set the inflatable seal valve (BJ) to deflate.
 4. Set the director valve (BC) to UP to raise the ram plate.
 5. If needed, use air assist (BG) to help lift the ram plate.
 6. Raise the ram plate until it is completely out of the drum. Remove the empty drum.

7. Disconnect inflatable seal supply air.
8. Pull the inflatable seal down to remove. Clean and sanitize the seal.

NOTE: Discoloration of the inflatable seal is normal. Replace the inflatable seal if the surface is compromised due to excessive wear, tears, cuts, or gouges.

9. Set the director valve to DOWN. Lower the ram plate.
10. Follow the **Pressure Relief Procedure**, page 12.
11. Disconnect all remaining air and fluid hoses, and remove air inlet and exhaust fittings.
12. Remove and clean the pump.

NOTE: The pump **must be disassembled** to thoroughly clean it. See your separate pump manual for complete flushing and cleaning procedures for a sanitary pump. Any damaged rubber parts **must** be replaced as they could harbor microorganisms that can contaminate the fluid.

13. Remove, clean, and sanitize the clamps (12, 13), ram plate (5) and seal (8).
14. Remove the air motor cover. Open the control box door. Wipe out any residual cleaning fluid or moisture.
15. Clean external surfaces of all parts before reassembly.


Troubleshooting

1. Follow **Pressure Relief Procedure**, page 12.
2. Check all possible remedies in the Troubleshooting Chart before disassembling the pump.



Problem	Cause	Solution
Ram will not raise or lower.	Closed air valve or clogged air line.	Open, clear.
	Not enough ram air pressure.	Increase.
	Worn or damaged piston.	Replace.
	Hand valve closed or clogged.	Open, clear.
Ram raises and lowers too fast.	Air pressure is too high.	Decrease.
	Travel rate is not properly adjusted.	Exposed Air Controls - open the director valve less for slower travel, more for faster travel.
Air leaks around cylinder rod.	Worn rod seal.	Replace.
Fluid squeezes past ram plate wipers.	Ram air pressure too high.	Decrease ram pressure.
	Worn or damaged wipers.	Replace.
	Inflatable seal pressure too low.	Increase seal pressure
Pump will not prime properly or pumps air.	Closed air valve or clogged air line.	Open, clear.
	Not enough air pressure.	Increase.
	Worn or damaged piston.	Replace. See pump manual.
	Hand valve closed or clogged.	Open, clear.
	Hand valve is dirty, worn, or damaged.	Clean, service.
Air assist valve will not hold drum down or push plate up.	Closed air valve or clogged air line.	Open, clear.
	Not enough air pressure.	Increase.
	Valve passage clogged.	Clean.
Seal pressure builds when drum tapers, activating the automatic pressure relief.	Seal bleed-off valve (BL) is closed	Open. See Integrated Air Controls , page 11.


Repair



Disconnect Piston Pump

1. Follow **Pressure Relief Procedure**, page 12.
2. Disconnect inflatable seal supply air and air assist supply air.
3. Remove two clamps (12) holding the tie rods (2) to the ram plate. Remove gaskets (7).
4. Remove nut (4) and washer (3) holding the air motor connecting rod (10) to the tie beam (114).
5. Open main air valve (BA). Set the director valve (BC) to UP to raise the ram. Set the director valve to neutral. Close main air valve (BA).
6. To remove the pump from the ram plate, remove clamp (13) and gasket (8). Carefully lift the pump up

and away from the plate, using two people if needed.



ti16470a

FIG. 4. Remove piston pump

NOTE: See your piston pump manual and air motor manual for cleaning, repair, and parts information.

Service Ram Pistons



Always service both cylinders at the same time. When you service the piston rod always install new o-rings in the piston rod seal and ram piston.

- Order Piston Repair Kit 24G853 for a stainless steel ram. Parts are marked with a † in the illustrations and parts list.
- Order Piston Repair Kit 24G854 for a carbon steel ram. Parts are marked with an * in the illustrations and parts list.

Disassemble Piston and Seal

1. Follow **Pressure Relief Procedure**, page 12.
2. Follow **Disconnect Piston Pump**, page 18.
3. Remove nuts (117) and lock washers (116) holding the tie bar (114) to the piston rods (102). Also remove nuts (4) and washers (3) holding the tie bar to the tie rods (2).
4. Stainless Steel Rams: Remove four screws (124) and washers (123), then remove the piston cap (120). Remove outer o-ring (121) and inner o-ring (122) from piston cap.
5. Remove retaining ring (115).
6. Carefully pull the piston rod out of the top of the cylinder.

NOTICE

Do not tilt the piston rod when removing it from the base or when installing it. Such movement can damage the piston or the inside surface of the base cylinder.

7. Slide the piston seal housing (103) and spring (104) up off of the piston rod (102). Remove outer o-ring (105) and inner o-ring (106) from the piston seal housing (103).
8. Remove retaining ring (112) and bearing (111) from the piston seal housing (103).




FIG. 5. Piston Rod Seal

T116472a

9. Carefully lay piston (107) and rod (102) down so rod will not be bent. Remove nut (108), washer (109), and piston (107). Remove outer o-ring (105) and inner o-ring (110).
10. Inspect parts for wear or damage. Replace as necessary.




FIG. 6. Ram Piston.


Reassemble Piston and Seal

1. Install new o-rings (105 and 110) and lubricate piston (107) and o-rings.
2. Apply medium strength thread sealant. Install piston (107), washer (109), and nut (108) on piston rod (102).

3. Carefully insert piston into cylinder and push piston rod straight down into cylinder.
4. Lubricate o-ring (106) and bearing (111). Install o-ring (106), bearing (111), and retaining ring (112) into piston seal housing (103).
5. Install new o-ring (105) on piston seal housing (103).
6. **Carbon Steel Rams:** Install new pin (113) if necessary, or be sure it is in place.
7. Lubricate o-ring (105) and piston seal housing (103).
8. Slide spring (104) and piston seal housing (103) on the rod (102). **Carbon Steel Rams:** orient the pin to the slot in the cylinder. **Stainless Steel Rams:** be careful not to push the piston seal housing down into cylinder.
9. Install retaining ring (115).
10. **Stainless Steel Rams:** Lubricate and install inner o-ring (122) into piston cap (120). Install outer o-ring (121) onto piston cap. Then install piston cap (120) onto the cylinder with screws (124) and washers (123).
11. Reattach the tie bar (114), washers (116, 3), and nuts (117, 4).

Parts

Piston Pump Ram Packages



ti37864a

Common Parts, All Piston Pump Ram Packages (5:1, 6:1, and 12:1)


Ref.	Part	Description	Qty
1	24G860	RAM, kit, includes Parts 1a, 14, 15, and 18; <i>see pages 23-24</i>	1
1a	-----	FRAME, ram, assembly, includes piston assembly	1
2	17S713	TIE ROD	2
3	512743	WASHER, flat 18-8 sst 7/8 in.	4
4	510221	NUT, hex st sst 7/8-9	4
5	25D541	PLATE, sanitary ram Standard design, used on most models	1
5a	25M452	FITTING 1/4 in. PTC	1
6	16G242	SEAL, inflatable, 18.0 id; includes Refs. 28 and 29.	1
7	16D169	GASKET, sanitary 1.5	2
8	16D246	GASKET, 6" sanitary	1
9	25D361	PUMP, sanitary, 5:1	1
10	17W11 17W13 17W12	ROD, air motor connecting Models with 5:1 pumps Models with 6:1 pumps Models with 12:1 pumps	1
10a	17W14	SCREW, hex, sst	1
11	101818	CLAMP, exhaust hose; <i>see page 24</i>	2
12	118598	CLAMP, sanitary, 1.5 in	2
13	16D245	CLAMP, 6" sanitary	1
14	16G396	CONTROLS, air; <i>see page 25</i> Exposed, carbon steel	1
15	-----	SCREW, shdc,ss,.500x1.00	1

Ref.	Part	Description	Qty
16	-----	HOSE, exhaust; <i>see page 24</i>	1
17	512914	MUFFLER, polyethylene, <i>see page 24</i>	1
18	-----	WASHER, back-up piston sst	1
19	101682	SCREW, cap, sch	2
20	100016	WASHER, lock	2
21	16A942	FITTING, exhaust hose	1
28	-----	FITTING, 1/4 ptc to 1/4 ptc, FDA, included with Ref. 6; <i>see page 24</i>	1
29	-----	FITTING, 1/4 ptc to 1/4 barb, FDA, included with Ref. 6; <i>see page 24</i>	1
34	-----	FITTING, 1/2 npt x 1/2 ptc, FDA; <i>see page 24</i>	1
36	120306 103347	VALVE, safety; shown on page 25 80 psi, Models with 5:1 pumps 100 psi, Models with 6:1 or 12:1 pumps	1
125▲	15J074	LABEL, warning, ram, not shown	1
126▲	280574	LABEL, warning, pump, not shown	1

----- Not available separately.

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

Ram Kit 24G860, Carbon Steel Frame



ti16273c

Ram Kit 24G860, Carbon Steel Frame

Each side contains the following parts.

Ref.	Part	Description	Qty.
14		CONTROLS, air; <i>see page 25</i>	1
	16G396	Exposed, carbon steel	
15	-----	SCREW, 1/2-13 unc, sst	1
18	-----	WASHER, sst	1
101	-----	RAM, frame	1
102	16G478	ROD, piston	2
103	15M295	BEARING	1
104*	160138	SPRING, compression	1
105*	160258	O-RING	2
106*	156698	O-RING	1
107	183943	PISTON	1
108*	101535	NUT	1
109*	101533	WASHER	1
110*	156401	O-RING	1
111*	-----	BEARING	1
112*	15F453	RING, retaining	1
113	15U979	PIN, spring	1
114	16G479	BAR, tie	1
115*	-----	RING, retaining, 3.06 dia	2
116	512743	WASHER, flat 18-8 sst 7/8 in.	2
117	510221	NUT, hex st sst 7/8-9	2
118	24G856	FITTING, Connector tube	2
125▲	15J074	LABEL, warning	4
126	189559	CAP, end	2

----- Not available separately.

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

* Parts included in carbon steel Piston Repair Kit 24G854 (2 kits required to repair both sides).

Muffler Kit 16G390

Ref.	Part	Description	Qty.
17	512914	MUFFLER, polyethylene	2

Exhaust Assembly Kit 16G389

Ref.	Part	Description	Qty.
17	512914	MUFFLER, polyethylene	1
16	-----	HOSE, exhaust, 6 ft.	1
11	101818	CLAMP, hose	2

PTC Fittings Kit 16G392


Ref.	Description	Qty.
28	FITTING, 1/4 ptc to 1/4 ptc, FDA	1
29	FITTING, 1/4 ptc to 1/4 barb, FDA	1
34	FITTING, 1/2 npt x 1/2 ptc, FDA	1

Conversion Kit 24H370

Order this kit to convert a ram with a 12:1 piston pump to a ram with a 3150 diaphragm pump.

Ref.	Description	Qty.
5	PLATE, ram	1
6	SEAL, inflatable, FDA, neoprene, 18 in. (46 cm)	1
8	GASKET, sanitary	1
9	PUMP, 3150, Model 24C124	1
13	CLAMP, 4 in.	2
21	FITTING, exhaust hose	1
28	FITTING, 1/4 ptc to 1/4 ptc, FDA	1
29	FITTING, 1/4 ptc to 1/4 barb, FDA	1
34	FITTING, 1/2 npt x 1/2 ptc, FDA	1
39	FITTING, air	1
40	CONNECTOR, union, 1/2 to 1/2 PTC	1

Air Controls Kits



 The safety valve is part of the ram package. See page 21 (piston pump packages).


Kit 16G396 Air Controls Carbon Steel, Exposed

Ref.	Part	Description	Qty
201	-----	CONTROL, air, includes 201a-201m	1
201a	-----	MANIFOLD	1
201b*	16Y167	VALVE, shutoff, modular, 3/4 npt	2
201c	121107	VALVE, control	1
201d*	121110	O-RING	3
201e	-----	REGULATOR	1
201f	121106	REGULATOR	1
201g	121109	VALVE, blow-off	1
201h*	121112	SCREW, cap	6
201j	517449	MUFFLER, 1/4 npt	1
201k	100721	PLUG, pipe, <i>not shown</i>	1
201m	120602	FITTING, cartridge, <i>not shown</i>	3
202	16E534	CONTROL, air assist option	1
203	-----	BRACKET, air control	1
204	100016	WASHER, lock	4
205	101682	SCREW, cap, sch	4
206	16A943	ELBOW, plug-in	2
207	100896	BUSHING, pipe	1
208	114111	CONNECTOR, male	1
209	C36260	GAUGE, pressure, air	2
210*▲	15V954	LABEL, valve, shutoff, air control (not shown)	1

* Parts are available in kit 121108.

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

Dimensions



TI15713a

Technical Specifications

Maximum Fluid Working Pressure	
5:1 Ratio Piston Pumps	410 (2.8 MPa, 28.3 bar)
6:1 Ratio Piston Pumps	650 (4.5 MPa, 44.8 bar)
12:1 Ratio Piston Pumps	1450 (10 MPa, 100.0 bar)
Maximum Package Air Inlet Pressure	
Piston Pump Ram Packages	100 psi (0.7 MPa, 6.9 bar)
Maximum Ram Air Inlet Pressure	100 psi (0.7 MPa, 6.9 bar)
Maximum Pump Air Inlet Pressure	
6:1 and 12:1 Ratio Piston Pumps	100 psi (0.7 MPa, 6.9 bar)
5:1 Ratio Piston Pumps	80 psi (0.6 MPa, 5.5 bar)
Maximum size pumpable solids	
5:1 and 12:1 Ratio Piston Pumps	1/4 in. (6.4 mm)
6:1 Ratio Piston Pumps	1/8 in. (3.2 mm)
Maximum Ram Package Operating Temperature	
5:1 Ratio Piston Pump Ram Packages	140°F (60°C)
All Other Ram Packages	150°F (66°C)
Maximum Drum ID	24 in. (61 cm)
Minimum Drum ID	
Straight-Sided Drum	19.4 in. (49 cm)
Tapered Drum	19.0 in. (48 cm)
Maximum Drum Height	40.75 in. (104 cm)
Sound Data	<i>See your pump manual.</i>
Wetted Parts	
Inflatable Seal	Neoprene
Ram (plate, fittings, gaskets)	300-Series Stainless steel, Buna-N, and Polypropylene
5:1 Ratio Piston Pumps (<i>see pump manual</i>)	Stainless steel, Buna-N, FKM, PTFE and UHMWPE. Priming piston pumps also have Polychloroprene and Nylon. Model 24F197 also has Silicone.
6:1 Ratio Piston Pumps (<i>see pump manual</i>)	Stainless steel, Buna-N, Polychloroprene, Nitrile, Nylon, and UHMWPE. Certain models have PTFE packings.
12:1 Ratio Piston Pumps (<i>see pump manual</i>)	Stainless steel, Acetal, Nitrile, PTFE, UHMWPE

Model Weights

Model No.	Weight	
	lb	kg
SDU.B01AAA6AA0C21	437	198
SDU.B01AAB6AA0C21	437	198
SDU.B02AAA6AA0C21	433	196
SDU.B02AAB6AA0C21	433	196
SDU.B03AAA6AA0C21	375	170
SDU.B03AAB6AA0C21	375	170
SDU.B04AAA6AA0C21	372	169
SDU.B04AAB6AA0C21	372	169
SDU.B05AAA6AA0C21	459	208
SDU.B05AAB6AA0C21	459	208
SDU.B01BBC7AA0C21	437	198
SDU.B02BBC7AA0C21	433	196
SDU.B03BBC7AA0C21	375	170
SDU.B04BBC7AA0C21	372	169
SDU.B05BBC7AA0C21	459	208

California Proposition 65

CALIFORNIA RESIDENTS

 **WARNING:** Cancer and reproductive harm – www.P65warnings.ca.gov.

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.

Phone: 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2020, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision ZAG, April 2020